

Glow Plug Tester



- Used to test diesel glow plugs in the engine
- No need to remove glow plugs from the engine
- Only to be used on 12 Volt DC Systems
- After 3 seconds the Glow plug tester will indicate faulty or OK on the glow plugs
- Multimeters can only test glow plugs in their off (cold state)
- This tester works by powering up the glow plug and measuring its operating current; the best way to give an accurate indication of the glow plug status