



ALB40200

www.albadiagnostics.com

Multi Application Tool

- Internet updateable multi-vehicle & multi-application diagnostics tool
- Now with ALL 4 software packages included;
 - Battery Validation, essential for ALL Start/Stop battery management (BAT)
 - Service Light Reset (SLR)
 - Electronic Parking Brake (EPB)
 - DPF Regeneration & Reset (DPF)
- J1962 compliant
- Access to both standard & discretionary diagnostic pins & protocols
- Compact design with high visibility display



BATTERY VALIDATION (BAT)

- Access to the battery control module
- Battery management fault codes
- Validate replacement batteries
- Change battery type (e.g. AGM to ECM)
- Standard technology on Stop/Start systems



SERVICE RESET (SLR)

- Reset dashboard service parameters & lights
- Service light reset
- Oil degradation
- Condition based servicing
- Long life service intervals
- Time & distance settings



ELECTRONIC PARK BRAKE (EPB)

- Opens rear hand brake mechanisms electronically, for replacement of brake pads
- Read & clear fault codes
- View live data and service modes
- Calibrate systems



DIESEL PARTICULATE FILTER (DPF)

- Read & clear DPF related fault codes
- Perform dynamic or static forced Regeneration of the DPF
- Replacement filter adaption & additive reset



Alba Diagnostics Ltd
Bankhead Avenue
Bankhead Industrial Estate
Glenrothes
Fife
KY7 6JG
T: 01592 774333
F: 01592 774777
sales@albadiagnostics.com



To find out more and for details of Alba's full range of Diagnostic Equipment check out the website @ www.albadiagnostics.com