



# ALB40208

[www.albadiagnostics.com](http://www.albadiagnostics.com)

## GLOW PLUG IMPACT SOCKET



Alba Diagnostics Ltd  
Bankhead AVENUE  
Bankhead Industrial Estate  
Glenrothes  
Fife  
KY7 6JG  
T: 01592 774333  
F: 01592 774777  
[sales@albadiagnostics.com](mailto:sales@albadiagnostics.com)



- Torque-limited impact wrench set designed for removal of diesel engine glow plugs
- Four position torque limiter - 10, 20, 30 & 40Nm - for controlled torque vibration
- Uses controlled impact torque to create vibration in order to loosen seized glow plugs
- Removes the risk of breaking glow plugs, or damaging the cylinder head
- Can also be used for removal of other seized threaded fasteners or plugs up to 12mm
- Includes: Torque-limited impact wrench 1/4 sq dr; Impact Glow Plug Sockets - 8, 9, 10, 11, 12mm; Impact Extensions - 50, 100mm; Impact Universal Joint