

BATTERY SUPPORT UNIT & CHARGER (12 & 24 V)



A powerful multipurpose professional battery charger & battery support unit (BSU). The battery charger features primary switched, computer controlled software technology that ensures the battery receives the maximum charge in the minimum time without damage. It is suitable for charging, AGM, Calcium/Calcium, Deep Cycle, Gel & Leisure battery types. The BSU function will provide a continuous 70 amp clean power supply for 12V systems and 60 amp for 24v systems. This unit is essential for maintaining the battery voltage during software downloads, programming, configuration & other 'key on engine off' workshop operations.

- 70 amp battery support function for ECU flashing / configuration
- Charging Current: 12V - 70 amp; 24V - 60 amp,
- Fully automated charging control
- Input voltage 190-255V AC 45-400Hz,
- Built in voltage display
- Battery recovery mode
- Wall Mountable
- Internal Cooling Fan
- Standard, Gel & AGM batteries

