

## Trolley Mounted Pressure Brake Bleeder for Drums



### **Pressure bleeding is the only method approved by brake manufacturers**

- Designed specifically to extract fluid directly from a new drum of fluid
- One person operation for cars, LCV & HGV clutches
- Adjustable pressure up to 4 bar
- 12V supply (car's own battery) so can be used in & outside workshop
- Supplied with ALB30564B cap adapter kit (includes ALB592B Alba patented multi vehicle cap)
- Waste fluid collection bottle with attaching chain
- Stainless steel construction for long life
- Brake fluid container (20–60L drum) can be secured directly on to trolley base
- Low flow pressure switch for pump shut-off when fluid runs low to prevent air entering the system (drum not included)

**Supplied complete with ALB30564B; Multi-vehicle cap & European cap kit**

